

Model name:

**BMS-IFMB0TLR-E**

## Safety instructions

### WARNING

Follow carefully these safety and installation instructions. Improper work may lead to serious harmful for your health and also may damage seriously the interface and/or the Air-conditioning unit.

- This interface must be installed by accredited technical personnel (electrician, installer, or technical personnel) and following all the safety instructions.
- Before manipulating the Air-conditioning unit, be sure it is completely disconnected from Mains power.
- Do not modify the unit. (A fire or an electric shock may occur)
- This interface must only be installed in a restricted access location by user.
- Do not install the unit in any of the following places.
  - Humid or wet place
  - Dusty place
  - Place exposed to direct sunlight
  - Place where there is a TV set or radio within one meter
  - Place exposed to rain (outdoors, under eaves, etc.)
- Use predefined cable and connect them certainly. Keep the connecting terminal free from external force. It may cause an exothermic or a fire.
- Strip the insulation from the cable that connects to the connector (RS-485 and A B bus) following the dimensions shown in the diagram below.
- When connecting the cable to the connector (RS-485 and A B bus), ensure the core wires do not protrude from the connector.
- Use two-core cabtyre cable.

## Installation instructions

- Disconnect the Air-conditioning from Mains Power.
- Fix the interface beside the Air-conditioning (wall mounting) following the instructions in the diagram below or install it inside the Air-conditioning (respect the safety instructions given above).
- Connect the interface to A B bus in any point of the bus. The A B bus is the bus that connects the Air-conditioning unit, and the wired remote controller, is a two-wire bus connecting terminals A B of both, this A B connection has no specific polarity.
- Connect the RS-485 bus to the connector RS-485 of the interface.
- Close the Air-conditioning unit and reconnect it to Mains Power.
- Follow the instructions on the user manual for configuring and commissioning the interface.
- Follow the instructions of the next page to configure the interface through on-board DIP-switches.


### NOTE

The cable used for connection of BMS-IFMB0TLR-E to A B bus can be any two-core cabtyre cable, the maximum distance for bus A B is 300 meters, consult the manual of the Air-conditioning for more details.

Respect the maximum distance of 500 meters for the bus, no loop or star topologies are allowed for RS-485 bus, a terminator resistor of 120 Ω must be present at each end of the bus to avoid signal reflections and also a fail-safe biasing mechanism.

### IMPORTANT:


- Use only one remote controller. A sub-remote controller cannot be connected when connecting this interface.



### NOTE

In its place there is a pair of cables to connect the Remote Controller. Use these cables to connect the AB bus. Check your Air-Conditioning user or service manual for more information.

## Configuration through micro switches



### S1 - MB Interface Setting

Switches 1 2 3 4	Description
↓ x x x	Connet Wired Remote Controller and/or Wireless Remote Controller (default setting)
↑ x x x	Not Connet Wired Remote Controller and Wireless Remote Controller.
x ↑ x x	Reserve.
x x ↑ x	Reserve.
x x x ↑	Reserve.

### S3 - Modbus slave address and baudrate

Add	Switches 1 2 3 4 5 6	Add	Switches 1 2 3 4 5 6	Add	Switches 1 2 3 4 5 6	Add	Switches 1 2 3 4 5 6	Add	Switches 1 2 3 4 5 6	Add	Switches 1 2 3 4 5 6	Add	Switches 1 2 3 4 5 6	Add	Switches 1 2 3 4 5 6
0	↓↓↓↓↓↓↓	8	↓↓↓↑↓↓	16	↓↓↓↑↑↓	24	↓↓↓↑↑↑	32	↓↓↓↑↑↑	40	↓↓↓↑↑↑	48	↓↓↓↑↑↑	56	↓↓↓↑↑↑
1*	↑↑↓↓↓↓↓	9	↑↑↓↑↓↓	17	↑↑↓↑↑↓	25	↑↑↓↑↑↑	33	↑↑↓↑↑↑	41	↑↑↓↑↑↑	49	↑↑↓↑↑↑	57	↑↑↓↑↑↑
2	↓↑↓↑↓↓↓	10	↓↑↓↑↑↓	18	↓↑↓↑↑↑	26	↓↑↓↑↑↑	34	↓↑↓↑↑↑	42	↓↑↓↑↑↑	50	↓↑↓↑↑↑	58	↓↑↓↑↑↑
3	↑↑↓↑↓↓↓	11	↑↑↓↑↑↓	19	↑↑↓↑↑↑	27	↑↑↓↑↑↑	35	↑↑↓↑↑↑	43	↑↑↓↑↑↑	51	↑↑↓↑↑↑	59	↑↑↓↑↑↑
4	↓↑↑↓↓↓↓	12	↓↑↑↑↓↓	20	↓↑↑↑↑↓	28	↓↑↑↑↑↑	36	↓↑↑↑↑↑	44	↓↑↑↑↑↑	52	↓↑↑↑↑↑	60	↓↑↑↑↑↑
5	↑↓↑↑↓↓↓	13	↑↓↑↑↑↓	21	↑↓↑↑↑↑	29	↑↓↑↑↑↑	37	↑↓↑↑↑↑	45	↑↓↑↑↑↑	53	↑↓↑↑↑↑	61	↑↓↑↑↑↑
6	↓↑↑↑↓↓↓	14	↓↑↑↑↑↓	22	↓↑↑↑↑↑	30	↓↑↑↑↑↑	38	↓↑↑↑↑↑	46	↓↑↑↑↑↑	54	↓↑↑↑↑↑	62	↓↑↑↑↑↑
7	↑↑↑↓↓↓↓	15	↑↑↑↑↓↓	23	↑↑↑↑↑↓	31	↑↑↑↑↑↑	39	↑↑↑↑↑↑	47	↑↑↑↑↑↑	55	↑↑↑↑↑↑	63	↑↑↑↑↑↑

\* Default value

Switches 7 8	Description
↓ ↓	2400bps
↑ ↓	4800bps
↓ ↑	9600bps (default value)
↑ ↑	19200bps

### S4 - Degrees/Decidegrees (x10), temperature magnitude (°C) and RS-485 termination resistor

Switches 1 2 3 4	Description
↓ x x x	Temperature values in Modbus register are represented in degrees (x1) (default value)
↑ x x x	Temperature values in Modbus register are represented in decidegrees (x10)
x x x ↓	RS-485 bus without termination resistor (default value)
x x x ↑	Internal termination resistor of 120Ω connected to RS-485 bus *

\* Only in the interfaces conected at both ends of the bus must be activated the termination resistor, not in the rest. The RS-485 bus can be biased through internal jumpers JP2 and JP3. Consult the user manual for details.

**NOTE**

When use RBC-AMS5\* Remote Controller, You cannot connect the following air-conditioner.

Type	Model
1-way Air Discharge Cassette Type	MMU-AP***4YH1
Concealed Duct High Static Pressure Type	MMD-AP***4H,-E
Floor Standing Concealed Type	MML-AP***4BH1,-E
Floor Standing Cabinet Type	MML-AP***4H1,-E
Floor Standing Type	MMF-AP***4H,-E
Fresh Air Intake Indoor unit Type	MMD-AP***1HFE
Air to Air Heat exchanger with DX-coil Type	MMD-VN***2HEX1E
Hot Water Module	MMW-AP***LQ-*

**电器电子产品有害物质声明****1. 环保使用期限标识的说明**

环保使用期限标识是根据《电器电子产品有害物质限制使用管理办法》以及《电子电气产品有害物质限制使用标识要求》(SJ/T11364) 制定的, 适用于中国境内销售的电器电子产品的标识。

只要按照安全及使用说明内容在正常使用电器电子产品情况下, 从生产日期算起, 在此期限内产品中含有的有害物质不致发生外泄或突变, 不致对环境造成严重污染或对其人身、财产造成严重损害。

产品正常使用后, 要废弃在环保使用年限内或者刚到年限的产品, 请根据国家标准采取适当的方法进行处置。

另外, 此期限不同于质量 / 功能的保证期限。

The Mark and Information are applicable for People's Republic of China only.

**2. 有害物质表示表**

< 产品中有害物质的名称及含量 >

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
塑料件	○	○	○	○	○	○
印刷电路板组件	✘	○	○	○	○	○
螺钉、垫片等紧固件	○	○	○	○	○	○

本表格依据SJ/T 11364的规定编制。

○ : 表示该有害物质在该部品所有均质材料中的含量在GB/T 26572的限量要求之下。

✘ : 表示该有害物质至少在该部品的某一均质材料中的含量超出了GB/T 26572规定的限量要求。

This information is applicable for People's Republic of China only.

注: 请将本申明与产品其他说明文件一同妥善保管。

产品出厂合格

# TOSHIBA CARRIER EUROPE S.A.S

Route de Thil 01120 Montluel France

DEB2029101